


THE FLEET TRAINER



THE BASIC FRAME WORK
OF THE FUSELAGE IS BUILT
FROM 1/8" SQUARE BALSA
AND IS SHOWN IN GRAIN.

THIN CELLULOID
MAKE THE COCKPITS FROM
1/16" SHEET
BALSA

FIVE CELLULOID
CYLINDERS ARE R'Q'D.

HOLLOW THE NOSE
BLOCK TO THICKNESS
OF BROKEN LINE.

REMOVABLE
NOSE
PLUG

1 1/2" DIA.
BALSA
WHEELS

LOWER
WING POSITION

1/16" SHEET FILL-IN

ALL FUSELAGE STRINGERS
ARE 1/16" SQUARE BALSA STRIPS.

BEND THE LANDING GEAR
TO SHAPE FROM .038 MUSIC
WIRE AND BIND IT TO THE
FUSELAGE WITH THREAD

MAKE THE HEADREST
FROM SOFT
AND LIGHT
BALSA.

SYDNEY STRUHL 1941.