

COVER WITH LOW TEMP  
FILM, or FOR A VERY TOUGH  
AIRCRAFT, USE A FABRIC  
SUCH AS 'COLOR TEX' BY  
CARL GOLDBERG OR SUPER COLDRITE  
WE ALSO RECOMMEND U.F.O.  
GLUE; IT WORKS LIKE C.A.  
BUT WILL NOT ATTACK  
FOAM. USE SPARINGLY

FILM  
ANY GAP  
YOU MAY  
HAVE WITH  
IT PUT WITH  
U.F.O.  
or Glue

SIDES FIT ON OUTSIDE  
of Bottom  
Mount MTH2 MT AS LOW as  
FUSE AS POSSIBLE

1" SLACK SHOLDER  
14 SIDES of BACK WALK  
of FUSE

Front  
View

Mount RUONER  
AFT AS FAR  
AS POSS.

1" up +  
DOWN  
Elev.  
ALL  
LIKE.  
YOU  
CAN  
GET

