



STAYED TO STICK
 METAL OF TP
 1/32" SHEET WED. GRAM VERTICAL
 EXTERNAL GRACE
 1/4" I.D. BRASS TUBE

TC 5/16" X 1/4" ALL PANELS
 LE 1/4" X 3/8" ALL PANELS

ALL BRGS
 1/8" X 1/8" SPRUCE
 POLYHEDRAL
 GRACE

POLYHEDRAL
 GRACE

ALL SKERT
 3/32"

RIGHT MAIN
 PANEL

CUSSETS,
 1/32" SHEET

COVERING
 SUPPORT,
 SCRAP FILL

1/32" TYP

1/4" X 1/2"
 AT FOOT,
 TAPER TO
 1/4" X 3/8" AT
 TP

TC 1/4" X 1/8"

3/32" BRASS
 TUBE

1/32" I.D.
 BRASS
 TUBE

1/4" I.D. BRASS TUBE

RIB 1
 2 REQ

3/32" SHEET 1
 3/32" SHEET

WING RIBBER DOUBLER
 1/8" PLYWOOD 2 REQ

POSITION WING RIBBER &
 DRILL FOR WOODEN TOOTH-PICK
 SCREW PINS TO HOLD RIBBERS

3/32" REQ

1/8" PLYWOOD

3/32" REQ

1/8" PLYWOOD

BLOCK UP
 STAB TP 3/4"

INSTALL SI
 AS SHOWN

RCS 1-5 3/32" SHEET 2 EACH

BUILD 2 -
 WING RIBBERS
 1/8" SHEET &
 1/4" X 1/2" STRIP

RIB 1: 3/32" PLYWOOD 6 REQ
 3/32" SHEET 2 REQ NO HOLES
 RIB 2: 3/32" SHEET 22 REQ
 1/8" SHEET 2 REQ

TP PLATE
 1/8" PLYWOOD 2 REQ

TAPER,
 1/4" FLY

SCREW EYES INTO
 WING PANELS

INSTALL SI
 AS SHOWN

3/32" X 1/2"
 HARDWOOD

3/32" PLYWOOD
 TRAPLER

1/4" BRASS
 TUBE

1/8" WIRE

CELLERACK PIVOT
 3/32" BRASS TUBING
 RIGHT TO FUSELAGE HOLES

1/8" SHEET

1/4" TRANGLE

ALL FORMERS
 1/8" SHEET

BALANCE POINT

1/4" UNFINISHED DRILL ROD
 REMOVABLE MATCH

1/2" DIA THRU

WEIGHT AS REQ
 TO BALANCE

WIRE

THE WEIRD ONE

FOR SIZE &
 BOTTOM
 1/8" SHEET

1/8" PLYWOOD

FOR MODEL SUPPLY
 NONSTABLE YOD
 BLOCK ASSEMBLY

1/8" PLYWOOD DOUBLER
 FROM KNOX TO HERE

1/8" PLYWOOD WED

1/4" X 1/8" TP

DESIGNED BY: BOB SAMPOLUS & ANN PEDERSEN
 DRAWN BY: BOB SAMPOLUS & TRACED BY: RAY BOWEN

