



SCALE STABILIZER OUTLINE



ALL THE Balsa USED IN CONSTRUCTION OF RUDDER AND STABILIZER IS $\frac{1}{16}$ " THICK

CEMENT THESE PIECES BETWEEN RIBS TO STRENGTHEN WING.




ENLARGED SKETCH OF FREE-WHEELING DEVICE.

PROP FOR FLYING-(SPINNER MAY BE OMITTED.)



THIS CAP IS CEMENTED ON AFTER THE REST OF THE SPINNER IS FINISHED. IT MAY BE HOLLOWED OUT TO ACCOMMODATE A FREE-WHEELER. SEE SKETCH.



BENT PIN