
1
2
3
4
5
1/32" sheet covering
a
b
c
9
10
11
12
13
14
.040 wire (dotted lines) to strengthen landing gear
nose block
all formers 1/16" sheet