





Note: This sheer web should be glued in place after the first side of the wing joiner socket is glued in place. The other sheer webs are added later after the ribs are in place.





Don't cut out the closed off notches until the top sheeting is in place.





19% scale	Sheet 2 of 4
Sukhoi SU-26MX	
Designed by: Erik Middeldorp email: edorp@hotmail.com	
Building notes & photos online at: http://homepages.ihug.co.nz/~nakica/	
Scale: 0mm 100mm	