


"FURNACE" FREE-FLITE MODEL



3/16" SQ. WING L.E.

7/8"

NOTCH L.E. 1/32"

TYPICAL RIB SPACING

3/32" x 3/16" SPAR

"A"

1-1/8"

4-3/8"

1/16" SHEET GUSSETS

DIHEDRAL JOINER

1/16" SHEET WING RIBS

1/8" x 1/2" WING T.E.

NOTCH T.E. 1/16"

WING PLAN

1/16" SQ. STIFFENERS

STAB PLAN

DIHEDRAL JOINER

1/8" SHEET WING TIP

1-5/16"

3/16"

1/16" SHEET GUSSETS

1/16" HARD SHEET

FURNACE

"A"

WING RIB LAYOUT

DIHEDRAL SKETCH

1/16" x 7/16" x 2" PLYWOOD WING PLATFORM

NOTCH FOR DIHEDRAL JOINER

DIHEDRAL JOINER

1/16" HARD SHEET

GLUE FILLET

FUSELAGE

WING MOUNT DETAIL

CABIN OUTLINE

WING CENTERSECTION

WING PLATFORM

NOTE: USE BALSA UNLESS OTHERWISE SPECIFIED.

FIN & RUDDER 1/16" SHEET

2-7/8"

5-11/16"

4-7/16"

1-1/16"

1/8" DIAM. WING DOWEL

TYPICAL SECTION

1/16" SHEET DORSAL

1-5/16"

WOOD SCREWS

C.G.

3/32" x 3/8" x 2-1/2" PLYWOOD MOUNT

FUSELAGE SIDE VIEW

1/4" HARD SHEET

STAB POSITION

1/16" SHEET SUB-RUDDER

7/8"

LEAD INSERT OR CLAY BALLAST IF REQUIRED FOR BALANCE

JETEX "PAA-LOADER" 150 AND CLIP

23-5/8"

SCALE IN INCHES