



17

- When sanding sealer and glue are completely dry, paint model with gloss white enamel.
- Follow instructions on spray can for best results.
- Let dry overnight. Mask off rocket and paint top 2 inches of rocket with gold enamel. Paint nozzles as shown.
- Remove mask from rocket as soon as paint has set.




18

- Remove any excess plastic with modeling knife or fine sandpaper.
- Sand both ends of clear payload tube flat.



19

- Cut off end of nose cone and discard.
- Sand end of nose cone flat and smooth.
- Trim or sand any excess plastic from around sides of nose cone.
- Wipe nose cone inside and outside with damp cloth to remove oil and dirt.
- Paint outside of nose cone silver enamel and inside of nose cone black.



20

- DO NOT CUT ADAPTER AND SATELLITE APART.
- Trim and sand any excess plastic from around the sides of adapter and satellite.
- Use a sharp knife to remove any excess plastic from the inside of the molded eyelet at rear of adapter.

