



3/8" SPRUCE SPARS
3/32" WEBS AFT OF SPARS
3/32" SHEETING
USE WICK HINGES
SOLID Balsa Wing Tips
ROUTE THROTTLE NYRDS AFTER NACELLE INST
DIHEDRAL SET AT 4 DEG OUTER WINGS
USE 1/8 PLY DIHEDRAL BRACES FOR & AFT

WARNING ----- MAKE SURE THE GAP IN THE NACELLE IS EXACTLY (2 9/16")
make up wing in three sections
install nyrods for throttle before sheeting top center section

W.T.F. RT. WING SECTION
DESIGNED JANUARY 1996